



# Xbox One Wireless Controller Thumbstick Replacement

Remove the thumbstick from the controller.

Written By: Garrett George



## INTRODUCTION

This guide will assist you in replacing your thumbstick. If you have a rogue thumbstick, you have come to the right place.

---

### TOOLS:

- [T8 Torx Screwdriver](#) (1)
- [Spudger](#) (1)

### PARTS:


- [Xbox One Controller Joystick Cover](#) (1)

## Step 1 — Battery Pack



- Remove the battery pack cover.
- Remove batteries.

## Step 2 — Side Handles



**i** We recommend using a nylon spudger for this step. A metal spudger is shown.

- Grip the controller firmly to remove the side handles, wedging a spudger into the seam between the front and handle plates.
- Pry the side plate away from the front plate by moving the spudger back and forth. You will need to do this all the way around the side plate's seam.

## Step 3 — Screws



- i There is a hidden screw located in the middle of the controller behind the label.
- Use a screwdriver and punch a hole directly in the center of the label.
- i You may also lift the label if you do not want to puncture it.
- Remove the five 10mm screws located on the back of the controller using the T8 Security Torx Screwdriver.

## Step 4 — Backplate



- Remove the backplate.

## Step 5 — Faceplate



- Remove the faceplate.

## Step 6 — Thumbstick



- Remove thumbsticks by pulling them up off their poles.

To reassemble your device, follow these instructions in reverse order.