



HP Chromebook 14-Q010DX Keyboard and Touchpad Replacement

Keyboard and touchpad replacement.

Written By: Wilfredo Ramos



INTRODUCTION

This guide will require removal of 13x7mm screws.



TOOLS:


- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)
- [Phillips #00 Screwdriver](#) (1)



PARTS:


- [HP Keyboard/top cover spare part #740172-001](#) (1)

Step 1 — Keyboard and Touchpad



- The yellow circle represents the rubber covering that protects the screw. And the red circle represents the screws.
- Flip the laptop such that the base of the laptop should face you. Remove the rubber covering with help of any sharp pointed object and then unscrew the screw.

Step 2




- Using a plastic opening tool or the spudger to separate the keyboard from the frame of the laptop.
- Gently lower the keyboard towards you to expose the wires attached beneath.

Step 3



- Lift the black flap in the left black rectangle and pull the blue ribbon gently towards you until it is disconnected.
- Lift the white flap in the right black rectangle and pull the blue ribbon towards you until it is disconnected.

Step 4



- Lift keyboard slightly and remove the strip gently so is not damaging any parts . The tape has no function other than to keep the wire tucked away.

Step 5



- Keyboard is now detached from the laptop and can be placed to the side.

To reassemble your device, follow these instructions in reverse order.