




GoPro Hero4 Black Midframe Housing Replacement


Written By: Thomas Sullivan



 **TOOLS:**


- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Metal Spudger](#) (1)
-

Step 1 — Midframe Housing




- Remove the faceplate by carefully prying around the edge using a plastic opening tool. Loosen the clips on the edge, then pull the faceplate off.
 - Use the tweezers to lift the faceplate from the rest of the device.
- The power button on the front of the GoPro may pop off. Ensure to align it properly during reassembly.

Step 2




- Using a #00 Phillips head screwdriver, remove the following screws:
 - One 4.6 mm screw
 - Three 8.2 mm screws
 - Two 6.1 mm screws

Step 3



- Insert a metal spudger between the back plastic housing and the camera board assembly. Working around the edge to be careful of the inner components, carefully remove the camera.

Step 4



- Using tweezers, remove the ribbon strip by pulling on it. This will remove the connection.
- Push down on the three wires with the metal spudger and the clip will disconnect from the motherboard.
- ☑ During reassembly, remove the black tape on the ribbon cable, turn the camera upside down so you can see the port, and reinsert the cable with tweezers. It's a lot easier!

To reassemble your device, follow these instructions in reverse order.