



How to remove swept screw with dremel mototool

I'm going to make a slot to put a flat screwdriver and take it out naturally. I used the dremel mototool and the engrave tips: 0.8 mm (108), 1.9 mm (110).

Written By: @HectorNavarroMX



INTRODUCTION

You must consider that you are going to splash metal remains, you must cover the motherboard.

TOOLS:

- [Rotary Tool](#) (1)
-

You should be carefully with this. You can damage moterboard.

This document was last generated on 2019-07-22 05:08:41 AM.