



Repairing Parrot AR.Drone Hull With Special EPP Tape

How to repair foam hull damage with EPP tape.

Written By: David Hoyt



INTRODUCTION

AR.Drone Hulls are shock resistant but a long fall can damage it. Just stick the parts together with EPP (Expanded Polypropylene) adhesive tape.

[video: <http://youtu.be/e3dEblGlgBs>]

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 10:13:15 PM.