



# Motorola Moto X 2nd Generation Power and Volume flex cable Replacement

Written By: Sophia



 **TOOLS:**

- [T3 Torx Screwdriver](#) (1)
  - [iFixit Opening Picks set of 6](#) (1)
  - [Spudger](#) (1)
  - [Tweezers](#) (1)
  - [SIM Card Eject Tool](#) (1)
-

## Step 1 — Power and Volume flex cable



- Remove SIM card tray.

## Step 2



- Remove back cover.

### Step 3



- Remove those two rubber cover.

### Step 4



- Release power connecting flex connector and battery connector.

## Step 5



- Twist off all 18 black torx screws and remove the middle housing from front assembly.

## Step 6



- Release power flex connector from connecting flex.



## Step 7



- Remove securing bracket and side buttons.

## Step 8



- Pry up and remove the power flex.

To reassemble your device, follow these instructions in reverse order.