



Mac Mini Mid 2011 Hard Drive Tray Replacement

Written By: Walter Galan



INTRODUCTION

Prereq only.

TOOLS:

- [T6 Torx Screwdriver](#) (1)
-

Step 1 — Hard Drive Tray



- Remove the 7.9 mm T6 Torx screw securing the hard drive tray to the outer case.

Step 2



- Remove the hard drive tray from the outer case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-20 06:39:15 AM.