


iMac Intel 21.5" Retina 4K Display (2017) Lower Support Bracket Replacement

Prerequisite for removing the lower support bracket in an iMac 4K 2017.

Written By: Jeff Suovanen



Guide ID: 100542 - Draft: 2019-10-07

INTRODUCTION


Prereq-only guide for removing the lower support bracket in an iMac 4K 2017.




TOOLS:

- Tweezers (1)
- Phillips #00 Screwdriver (1)


Step 1 — Lower Support Bracket





- Remove the following five Phillips screws holding the lower support bracket in place:
 - Four 3.2 mm screws
 - One 1.7 mm screw
- You may need to peel up the display adhesive lining the bottom edge of the iMac enclosure to access the screws.

Step 2



 Remove the lower support bracket (a.k.a. "chin strap") from the iMac enclosure.

To reassemble your device, follow these instructions in reverse order.