



Shark Navigator Freestyle SV1106 Roller Brush Replacement

This guide will demonstrate how to safely and properly remove and replace the Shark Navigator Freestyle's roller brush.

Written By: Zachary Liu





INTRODUCTION

If your roller brush is not working even after removing surrounding debris, it is time to replace the roller brush.

TOOLS:


- [Coin](#) (1)
-

Step 1 — Roller Brush



- Remove the black rubber band from the roller brush
- ⓘ In most models there will be a plastic cover over the rubber band. You will use the quarter to twist the latch and take off the cover

Step 2



- Use the bristles to pull the end of the brush that was connected to the belt away from the vacuum.

Step 3

- Slide the roller belt off of the roller brush and pull the roller away from the motorized brush.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-15 05:00:46 PM.