



Instant Pot Smart-60 Steam Release Handle Replacement

Replace the steam release handle of the Instant Pot Smart-60.

Written By: paola alvarez



INTRODUCTION

The steam release handle can wear out over time and needs to be replaced. This guide will show step by step how to remove and replace the float valve of your Instant Pot Smart-60.

Step 1 — Steam Release Handle



- Grasp the steam release handle.
- Remove the handle by pulling upward.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-03-24 03:56:46 AM.