



# Lenovo IdeaCentre AIO 510S-23ISU Removing the Stand Base Replacement

This is a prerequisite to replacing any of the parts found in this device page.

Written By: Jackson Blake



## INTRODUCTION

The stand base on this computer stops the back cover from being removed, preventing you from accessing the components inside. No tools are needed for this, as it is designed to be screwed and unscrewed by hand.

---

### TOOLS:

- [Fingers](#) (1)
-

## Step 1 — Stand Base



- Turn off the computer, unplug all cables, and let it cool down. Lay the computer flat on its screen.
- ⓘ Make sure that the work surface is flat and has nothing sharp on it.

## Step 2



- Remove the monitor stand screw in the bottom of the stand, and remove the stand completely.

To reassemble your device, follow these instructions in reverse order.

