



Hoover Power Scrub FH50150 Handle Replacement

This Guide will show you how to replace the handle.

Written By: Leo



INTRODUCTION

This Guide shows you how to replace the handle.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Handle Replacement



- Push the button on the top of the clean water/solutions tank and pull on the handle below the button simultaneously. The tank should easily swing out.

Step 2



- Using the screwdriver, unscrew both of the screws on the backside of the handle.

Step 3



- Pull the handle upwards. It should freely slide away from the base of the machine.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-04-07 11:13:52 PM.