



HP Deskjet 1000 J110a Parts Replacement

How to remove the panel to replace a part in the HP Deskjet 1000 J110a.

Written By: Colin Tourjee



INTRODUCTION

These steps must be followed before replacing any internal parts in the HP Deskjet 1000 J110a. Don't forget to keep track of the screws.

TOOLS:

- [T10 Torx Screwdriver](#) (1)
-

Step 1 — Cover Removal



- Remove the two 13 mm screws located on the back of the printer using a screwdriver with the T10 torx bit (star-shaped).

Step 2



- In the front of the printer, open the tray where the paper comes out and remove the two 13 mm screws located under the top of the printer.

Step 3



- With the front of the printer facing you, lift and raise the left side of the panel (like opening a book in reverse) until it disconnects from the clip on the right side of the panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-06-06 04:50:32 AM.