



eMac RAM Door Replacement

This guide shows how to replace the RAM access panel for your eMac.

Written By: Chris Green



INTRODUCTION

The eMac includes a user service door that allows access to the RAM, AirPort card, and clock battery. It's incredibly easy to remove.

TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Door Removal



- It should be noted that these guides are written based on a late-model eMac (2005, 1.42GHz, DDR). They will differ slightly from the older model eMacs that use PC-133 RAM.
- Lay the eMac screen-down on a flat surface. I've found it convenient to use a carpeted floor because the computer is so heavy.
- Remove the single phillips #2 screw on the RAM door, and remove the door
 - The screw is captive in the door, so don't worry about losing it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-05-14 12:45:28 AM.