




Dell Vostro 5560 Battery Replacement

Written By: Johnathan Hammond




INTRODUCTION

In this guide, we will show you how to remove and replace the Battery.

TOOLS:



- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Removing The Optical-Disk Drive



- Remove the screw that secures the base cover to the computer.
 - Pull the optical-disk drive and remove from the computer.
- ☒ If this is all you are doing Follow Step In Reverse if not Go to Next Step.


Step 2 — Replacing the Base Cover



- Remove the screws that secure the base cover to the computer.
- Pry the base cover along the edges to loosen it. Lift and remove the base cover from the computer.

☒ If this is all you are doing Follow Step In Reverse if not Go to Next Step.

Step 3 — Removing the Battery



- Disconnect the battery cable from its connector on the system board.
 - Lift and remove the battery from the computer.
- ★ If this is all you are doing Follow Step In Reverse if not Go to Next Step.

This document was last generated on 2018-06-23 03:20:56 AM.