




Vizio CT15 Display Replacement

This guide provides instruction to replace a broken or nonfunctional Vizio CT15 display screen.

Written By: Brian Patino



INTRODUCTION

This guide will help users remove a broken Vizio CT15 display screen.

TOOLS:

- [Spudger](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Vizio CT15 Back Panel Removal



- Turn the laptop off and remove all power cables.
- Remove the six Phillips #0 screws.
- Pull the back cover off.

Step 2 — Battery






- Remove the six Phillips #0 screws.

Step 3





- Use the plastic opening tool or your fingers to pry the battery up and pull it from the laptop.

Step 4 — Display



- Using your fingers, unplug the wires.

Step 5



- Remove the six Phillips #0 screws.
- Disconnect the display from the laptop base by pulling the two apart from each other.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-24 12:09:36 AM.