



Dell Vostro 3561 Battery Replacement

How to replace the battery of a Dell Vostro 3561.

Written By: Johnathan Hammond



INTRODUCTION


In this guide, we will show you how to remove and replace the Battery.

Step 1 — Sliding the Battery Release Latch



- Flip the computer over.
- Slide the battery release latch to the unlock position.

Step 2 — Slide the Battery Release Latch



- Slide the other battery release latch to the unlock position.

Step 3 — Removing the Battery



- Slide the battery and remove it from the computer.
- ☑ If this is all you are doing Follow Step In Reverse if not Go to Next Step.

This document was last generated on 2019-08-25 05:59:29 PM.