



Logitech G700s Skates Replacement

Logitech G700s Mouse Skates replacement guide.

Written By: Chase Tisinger



INTRODUCTION

A guide on how to remove and replace the skates on a Logitech G700s mouse.



TOOLS:

- [iFixit Opening Tools](#) (1)
- [Paper Towels](#) (1)



PARTS:

- [Mouse Glide Pads](#) (1)
-

Step 1 — Mouse Skates



- Use a plastic opening tool to peel up the four skates from the bottom of the mouse.

Step 2



- Using a towel with isopropyl alcohol, remove the old glue left behind from the removed skates.

To reassemble your device, follow these instructions in reverse order.

