



HP Pavilion Sleekbook 15-b000 Battery Replacement

Removing or replacing the battery for a HP Pavilion Sleekbook 15-b000 Battery Replacement

Written By: Sam Barkley



INTRODUCTION

The battery is one of the main components needed to keep your laptop powered. This guide will show you how to replace your battery if you are having issues with your laptop running out of power when it is not plugged into the wall. It is one of the first steps in making any other repairs to the laptop.

Step 1 — Battery



- Unplug laptop from adapter and all other devices.

Step 2



- Flip the laptop over with battery facing you.

Step 3



- Slide the battery lock on the right side open.
- Slide the Battery release latch on the left side.

Step 4



- Pull battery out.

To reassemble your device, follow these instructions in reverse order.