



Toshiba Satellite L855-S5119 Battery Removal

Dead or broken battery replacement on a Toshiba Satellite L855-S5119 laptop.

Written By: Tyler Shafer



INTRODUCTION

This guide informs readers on the removal and replacement the battery in the Toshiba Satellite L855-S5119. For safety reasons, it is essential to remove the battery prior to operating on the laptop's internals.

Step 1 — Battery



- Turn the laptop face down to expose the back.
- Locate the battery.

Step 2



- i** Locate the battery latches. The battery latch mechanism can be compared to a door -- The right latch, when pushed right, unlocks the battery, while the left latch, when pushed left, releases the battery, pushing it out from its container.
- Push the latch on the right to the right to unlock the battery latch locking mechanism.
 - Push the battery latch on the left to the left to unlock the battery.

Step 3



- With the left battery latch pushed left, remove the battery from its port by lifting the battery from the middle of the battery.
- The battery will come free.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-13 11:58:32 PM.