



# Dell Vostro 3400 Battery Replacement

Written By: Johnathan Hammond



## **INTRODUCTION**

In this guide, we will be showing you how to remove and replace the Battery.

## Step 1 — Sliding the Battery Release Latch




- Slide the battery release latch to the unlock position.

## Step 2 — Sliding the Battery Release Latch



- Slide the other battery release latch to the unlock position.

### Step 3 — Sliding the Battery



- Slide the battery and remove it from the computer.

This document was last generated on 2018-06-23 03:23:19 AM.