Hasee Z7M-i78172D1 Keyboard Key Replacement

This guide will show you how to replace a key on the Hasee Z7M-i78172D1.

Written By: Desiree Mora

    www.iFixit.com

TOOLS:

- iFixit Opening Tools (1)

www.iFixit.com

Step 1 — Keyboard Key

- Using a plastic opening tool, gently pry the key up.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-24 05:44:10 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 3 of 3