



Dell Vostro 3300 Battery Replacement

Written By: Johnathan Hammond



INTRODUCTION

In this guide, we will show you how to remove and replace the Battery.

Step 1 — Sliding the Latch



- Slide the battery release latch to the unlock position.

Step 2 — Sliding the Latch



- Slide the other battery release latch to the unlock position.

Step 3 — Slide the Battery



- Slide the battery and remove it from the computer.

This document was last generated on 2018-06-23 03:24:30 AM.