




# Dell Vostro 15 3565 Base Cover Replacement


Written By: Johnathan Hammond



 **TOOLS:**


- Phillips #0 Screwdriver (1)
  - Spudger (1)
-

## Step 1 — Battery




- Slide the release latch to unlock the battery [1].
- Remove the battery from the computer [2].

## Step 2 — Optical-Disk Drive



- Remove the screw that secures the optical drive to the computer [1].
- Using a plastic scribe push the tab to release the optical drive [2].
- Slide the optical drive out of the computer [3].

## Step 3 — KeyBoard



- Release the keyboard by prying on the keyboard release tabs by using a scribe.

## Step 4




- Slide and lift the keyboard to access the keyboard connector cable under the keyboard [1,2].

## Step 5




- Disconnect the keyboard cable from the system board [1].
- Lift the keyboard cable to remove it from the computer [2].

## Step 6 — Base Cover



- Disconnect the optical drive connector and lift it to remove it from the system board [1,2]
- Remove the screws inside the palmrest [3].

## Step 7



- Remove the screws that secure the base cover to the computer [1].
- Pry the edges of base cover and lift it to remove it from computer [2].

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-22 10:33:56 PM.