



Razer Blackwidow Tournament Edition Chroma Front Panel Replacement

This guide shows you how to remove the front panel on the Razer Blackwidow Tournament Edition Chroma.


Written By: Jonathan Stewart



TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Rubber Feet



- Turn the keyboard over so that it is lying flat on its face.
- Use the iFixit opening tool to pry the rubber feet off the keyboard.

Step 2 — Front Panel



- Use a Phillips #1 screwdriver to remove the six screws on the back of the keyboard.
- Then use the IFixit opening tool to pry off the front panel.
- Place the keyboard over so the keys are facing up.
- Lift both ends of the keyboard up removing the front panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-05-25 07:28:37 PM.