



## **Dell Vostro 15 3549 Battery Replacement**

Written By: Johnathan Hammond



## Step 1 — Battery



- Slide the latches outward [1]
  - Release the battery [2].
    - Lift the battery to remove it from the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-05-10 02:52:28 PM.