



# Dell Inspiron 17-5749 Battery Replacement

Replace your battery to increase battery life and restore usability to your Dell Inspiron 17-5749.

Written By: Christopher Tran



## INTRODUCTION


This guide will instruct users on the process of replacing a battery on the Dell Inspiron 5749.

## Step 1 — Battery



- Turn off power to laptop.
- Unplug charging cable from laptop.
- ⚠ Failure to unplug the charging cable could result in damaging the computer or seriously injuring yourself.
- ⓘ Wear the anti-static wrist strap to prevent any electrical shock to the components. Shocks may damage the components.

## Step 2



- Carefully turn the laptop over.
- Switch each of the battery latches to the "unlocked" position.
- Pull battery upwards by the tab to remove from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-18 02:32:50 PM.