



Dell Inspiron 17-5749 Hard Drive Replacement

This guide will instruct users on how to replace or remove their current hard drive.

Written By: Christopher Tran



 **TOOLS:**


- [iFixit Opening Tools](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Turn off power to laptop.
- Unplug charging cable from laptop.
- ⚠ Failure to unplug the charging cable could result in damaging the computer or seriously injuring yourself.
- ⓘ Wear the anti-static wrist strap to prevent any electrical shock to the components. Shocks may damage the components.

Step 2




- Carefully turn the laptop over.
- Switch each of the battery latches to the "unlocked" position.
- Pull battery upwards by the tab to remove from the laptop.

Step 3 — Back Cover



- Remove the two 5.5mm screws that secure the base cover to the computer's base.
- Using the plastic opening tool, carefully pry open the base cover starting from the center.
- Lift the base cover upwards to remove and set it aside.

Step 4 — Hard Drive



- Remove the 2.5mm screw that secures the hard-drive assembly to the computer base.
- Using the pull tab, slide the hard-drive assembly to disconnect it from the system board.
- Lift the hard-drive assembly off the computer base

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-08-06 01:38:11 PM.