





## **INTRODUCTION**

This guide will teach you how to remove the battery from your laptop.

## Step 1 — Battery



- Place the laptop facedown with the battery facing you.
- Push the switch above the battery to the right and hold it in that position.
- Lift the battery using the grip on the top and remove it from its socket.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-05-24 08:47:04 PM.