



HP Pavilion 15-ab243cl CD Drive Replacement

Replacement of the CD ROM/CD Drive.

Written By: Alexander Bicigo




INTRODUCTION

This is a simple and straight forward procedure to replace the CD-Drive on your device. If your CD-drive has failed and will no longer read discs, then following this guide will help you regain a functioning drive.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — CD Drive



- Locate the screw, will have a CD symbol next to it, and remove this 3.5 mm screw with a PH0 screw driver.

Step 2



- Using your finger nail or a plastic opening tool, pull out the drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-05-29 01:19:21 AM.