



Panasonic Lumix DMC-FX9 Battery Replacement

How to replace your Panasonic Lumix DMC-FX9 Battery.

Written By: Davalynn Quiroz



INTRODUCTION


This guide will teach you how replace your Panasonic Lumix DMC-FX9 battery.

Step 1 — Battery



- Slide the tab to the left to open the battery cover.

Step 2



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

