



# Acer Aspire 5740-5780 Battery Replacement

This is a guide to remove and replace the battery of the Acer Aspire 5740-5780.

Written By: Gian Farrell



## INTRODUCTION

This guide shows how to remove and replace the battery of the Acer Aspire 5740-5780.

## Step 1 — Battery



- Unlock the battery by flipping a switch near the release latch.

## Step 2



- Slide the release latch. This will release the battery from the PC.

### Step 3



- Using your hands, pry the battery free of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-12 12:25:15 AM.