



# HP 15-ac142dx Battery Replacement

Successfully guide you with descriptive instructions on how to replace the battery.

Written By: Nicole Mathieu



## Step 1 — Battery



- Turn off the computer and flip it upside down and place on a flat surface
- Push the battery lock on both sides, sliding them to each other, to unlock the battery
- Lift the battery from the center and remove

## Step 2



- Take the new battery and line it up with the slot.
- Insert it in and when you here a click you will know it is in place

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-06-12 01:45:07 PM.