



# HP Envy dv6-7363cl Battery Replacement

This is a guide showing how to replace the battery of your HP Envy dv6-7363cl.

Written By: dylananthony



---

## INTRODUCTION

Reader will be able to successfully replace their battery in the device. Charging cable must be unplugged from device before attempting.

---



### PARTS:


- [HP TouchPad Battery](#) (1)
-

## Step 1 — Battery




- Flip the device upside-down so that its bottom is facing up.

## Step 2



- Push the lever underneath the battery to the left as shown in the picture.

### Step 3



- Lift the battery up out of its socket.

To reassemble your device, follow these instructions in reverse order.