




Dell Inspiron 14R-5421 Battery Replacement

Unlock and replace the battery

Written By: Jared paiva



INTRODUCTION



This guide will show you how to remove the battery from your laptop.

Step 1 — Battery



- Before you begin, make sure your laptop has been turned off.
- Gently turn your laptop over.

Step 2



- Find the two sliders that lock the battery in place.
- To remove the battery, press your fingers against the two sliders and push in the direction of the red arrows.
- Remove the battery when it pops up.

To reassemble your device, follow these instructions in reverse order.

