




Dell Inspiron 14R-5421 Battery Replacement

Unlock and replace the battery

Written By: Jared paiva



INTRODUCTION



This guide will show you how to remove the battery from your laptop.

Step 1 — Battery



- Before you begin make sure your laptop has been turned off.
- gently turn your laptop over

Step 2



- find the two sliders that lock the battery in place
- To remove the battery press your fingers against the two sliders and push in the direction of the red arrows.
- The battery should pop up when done correctly.

To reassemble your device, follow these instructions in reverse order.

