



Dell Precision M4500 Hard Drive Replacement

Written By: Johnathan Hammond



 **TOOLS:**

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Slide the battery release latches to the unlock position.
- Slide and remove the battery from the computer

Step 2 — Base Cover



- Loosen the captive screw that secures the access panel to the base of the computer.
- Slide the access panel towards the front of the computer.
- Lift the access panel up and away from the computer.

Step 3 — Hard Drive



- Remove the screws that secure the hard drive to the computer.
- Slide the hard drive out of the computer.
- Remove the screw that secures the face plate to the hard drive.
 - Pull out the face plate to remove it from the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-16 07:38:55 PM.