



Samsung Galaxy S7 Active Disassembly

How to disassemble the screen of Samsung Galaxy S7 Active.

Written By: Chengbin Owen Kuang



INTRODUCTION

This guide will shows you how to disassemble the screen of Samsung Galaxy S7 Active.



TOOLS:

- [Heat Gun](#) (1)
- [Metal Spudger](#) (1)
- [Tweezers](#) (1)



PARTS:

- [Samsung Galaxy S7 Active Screen](#) (1)

Step 1 — Samsung Galaxy S7 Active Disassembly



- Melt the adhesive on the screen by applying a blow dryer directly on the screen.
- ⚠ Your phone is hot, please do not touch it with your bare hand.

Step 2



- Wedge the metal spudger in between the screen and the frame to begin separating them.
- ⓘ It would be easier to separate the screen from the sealing adhesive on the frame if you with more than one metal spudger.
- ⓘ Your phone might no longer be watertight after you reassemble it.

Step 3



- Slide the metal spudger around the phone at least once.
- ⓘ It would be easier to slide your metal spudger if you apply the blow dryer to where you are currently sliding.

Step 4



- Lift the screen up with your hands.
- ⚠ Please wash your hands thoroughly with hot water and soap after you finish.

To reassemble your device, follow these instructions in reverse order.