



HP Pavilion G6-1d16dx Battery Replacement

When you push or hold on the power button, nothing happens. The computer appears to be completely dead.

Written By: Shyanne Bolton



INTRODUCTION

This concise guide outlines how to replace the battery. Replacing the battery is very easy; this guide outlines that process through 3 short steps.


TOOLS:

- [Fingers](#) (1)

PARTS:


- [HP MU09XL Replacement Laptop Battery](#) (1)

Step 1 — Battery



- Flip the computer so that the bottom side is facing up, and locate the battery above the screen hinges.

Step 2



- Slide the switch under the battery compartment to release the battery.

Step 3



- The battery will pop out above the latch; now remove the battery.

To reassemble your device, follow these instructions in reverse order.