



# Unplugging Shure SM58 XLR Cable

This guide shows you how to pull the XLR cable out of the microphone.

Written By: nat coll



## **INTRODUCTION**

The XLR cable connects the microphone with the sound mixer and speakers.

## Step 1 — Unplugging Shure SM58 XLR Cable



- Hold the microphone in one hand.
- Depress the button on XLR cable with the other hand.

## Step 2



- Pull the XLR cable out.
- ⓘ If XLR won't detach or microphone connector comes out with cable, see [XLR Cable Guide](#).

To attach the cable to the microphone, line up the holes in the cable with the three pins in the microphone base. Then push the cable into the base of the microphone until you hear a click.

