




Dell Inspiron 14z 1470 Battery Replacement


Written By: Teren Wallace



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

Step 1 — Turn the Computer Over




⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer. Follow the procedures in [Before You Begin](#).

⚠ CAUTION: To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface.


- Turn the computer upside down on a clean, flat surface.

Step 2 — Sliding the Latch



- Slide and click the battery release latch.

Step 3 — Sliding the Battery



- Slide the battery out of the battery bay.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-06-05 11:23:27 AM.