



Dell Inspiron 15 3565 Battery Replacement

Written By: Terrence15



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

Step 1 — Sliding the Battery Latch



⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before Working Inside Your Computer](#). After working inside your computer, follow the instructions in [After Working Inside Your Computer](#).

- Slide the battery-release latch to the unlocked position.
- ⓘ You hear a click sound when the battery is unlocked.

Step 2 — Turn the Computer Over



- Using your fingertips, lift the battery at an angle and remove it from the battery bay.

Step 3 — Grounding the System Board



- Turn the computer over, open the display, and press the power button for five seconds to ground the system board.

Step 4 — Close the Display



- Close the display and turn the computer over.

Step 5 — Installing the Battery



- Place the battery in the battery bay and snap the battery into place.

This document was last generated on 2019-07-17 01:24:46 AM.