




Dell Inspiron 15-5558 Memory Modules Replacement


Written By: Teren Wallace



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Memory Modules.


Step 1 — Popping up the Memory Module



⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before Working Inside Your Computer](#). After working inside your computer, follow the instructions in [After Working Inside Your Computer](#).

- Use your fingertips to carefully spread apart the securing clips on each end of the memory-module slot until the memory module pops up.

Step 2 — Remove the Memory Module




- Remove the memory module from the memory-module slot.

Step 3 — Align the Notch



- Align the notch on the **NEW** memory module with the tab on the memory-module slot.

Step 4 — Remove the Memory Module



- Slide the memory module firmly into the slot at an angle and press the memory module down until it clicks into place.
- i** NOTE: If you do not hear the click, remove the memory module and reinstall it.

This document was last generated on 2018-07-21 02:01:15 PM.