



Logitech Mouse M557 Disassembly

Logitech Mouse M557 Disassembly Unmounting Logitech M557 Mouse in an Easy Way.

Written By: Vinicius Iannuzzi



INTRODUCTION

- 1 - Remove the cover where you replace the battery.
- 2 - Below each battery there is a screw that you remove with a small philips screwdriver.
- 3 - At the top of the back part of the mouse there are two rubber finishes that you remove (it has an adhesive) and there you will find the screws that hold the top.
- 4 - It gets loose immediately, please be careful with the wire that connects one part to another, please disconnect this wire.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Logitech Mouse M557 Disassembly



- Remove the battery housing screws on the bottom.

To reassemble your device, follow these instructions in reverse order.