



Gigabyte Aero 15x Disassembly

This is how to remove the backplate to insert new storage, replace memory or anything else

Written By: Kev



INTRODUCTION

You just need:

- > 1 screwdriver Tors TR6
- > 1 screwdriver Philips classical Cross little
- > courage and bravery :)



TOOLS:

- [TR6 Torx Security Screwdriver](#) (1)
-

Step 1 — Remove the screws





- With Torx T6, you can remove the 13 screws. Follow their emplacement because 3 of them are taller (orange on picture 2)

Step 2 — Unclip the lower case



- Using plastic tools, you can start unclipping the hood from the front of the machine. Insert one opening tool and insert a second. Slide the tools around to pop off the bottom of the laptop.
 - ⚠ Do not insert your tool too deeply, to avoid hanging a clip.
- Do not unclip the back face fully; only the front and the two sides. You can nevertheless detach the 4 corners.
- ⓘ Photo 3 shows the location of the clips to dislocate in green. In red, these are the "hinges" of the hood (see next step)

Step 3 — Remove the lower case



- ⓘ Before removing the hood, remember that it is held by 2 aluminum rails at the back (hinge side).
- Remove the hood starting at the front two corners. Lift up at those corners.
- ⚠ Do not force if you encounter a hard spot, the metal could bend. You can use leverage with a small tool if necessary.

Step 4 — You're finished!



- Congratulations!

To reassemble, follow these steps in reverse order.

This document was last generated on 2019-08-23 09:22:03 PM.