



# IBM ThinkPad T30 Battery Replacement

A guide showing how to remove and replace the battery from the IBM ThinkPad T30.

Written By: Allie Knauer



## INTRODUCTION

Use this guide to remove your battery.

## Step 1 — Battery



- ⓘ Make sure the ThinkPad is off and the power supply is unplugged.
- Flip the ThinkPad upside down with the bottom facing you.
- Slide the latch on the underside of the ThinkPad to the right into the unlock position.
- While holding the latch in the unlock position, lift the battery out with your other hand.

To reassemble your device, follow these instructions in reverse order.