



iMac G5 20" Model A1145 Access Door Replacement

Written By: Andrew Bookholt



INTRODUCTION

Remove the access door to replace RAM chips.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Access Door



- Orient the iMac face-side down on a table with the bottom edge facing yourself.
 - Remove the two Phillips screws securing the access door to the bottom grille of your iMac.
- i** The screws are captive in the access door.
- !** **Before beginning the repair, unplug the computer and press and hold the power switch for 20-30 seconds, to discharge internal capacitors.**

Step 2



- Remove the access door.

To reassemble your device, follow these instructions in reverse order.

