




Asus ROG G750JM-BS17N23 Hard Drive Replacement

Repair or replace your hard drive on the Asus ROG G750JM-BS17N23.

Written By: Tanner



INTRODUCTION

If you are having issues with low hard drive space, use this guide to replace your hard drive.

TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Back Plate



- With the computer upside down, lift up on the rubber cap on the back plate to access the captive Phillips #2 screw.

Step 2



- Retract the Phillips #2 screw until the cover is loose.
- ⓘ The screw will not come all the way out.

Step 3





- Pry around the edges of the plate using a plastic opening tool until the plate is removed.

Step 4 — Hard Drive



- To access the hard drive, remove the back plate.

Step 5



- Remove the three 4mm Phillips #2 screws.

Step 6



- Pull back on the tab on the hard drive shield until it is clear of the screw slots. Next pull the shield out.

Step 7



- With the hard drive exposed, pull the hard drive away from the connection point and then remove the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-01-15 05:12:41 AM.