



Shark Flex DuoClean Garage Door Replacement

How to remove the garage door of the Shark Flex DuoClean HV391 Vacuum.

Written By: caoimhe



INTRODUCTION

To access the parts of the vacuum, remove the garage door.

Step 1 — Garage Door



- Open the garage door by sliding both of the release buttons away from you.
- Lift off the garage door.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2018-12-11 10:26:39 PM.