





Black and Decker PHV1810 Hand Vac Nozzle, Filter, and Catch Bowl Replacement

How to replace the nozzle, filter, and catch bowl of the Black and Decker PHV1810 Hand Vac.

Written By: Nicholas marsoobian



Step 1 — Nozzle, Filter, and Catch Bowl



- To take off the nozzle, filter, and catch bowl first start off by pushing in the button identified with a red square and twist that part of the device toward the handle portion of the vacuum and it should click and pop off the chassis.

Step 2



- Once the nozzle, filter and dust bowl have been removed each part can be removed from the nozzle section of the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2019-07-22 08:00:01 PM.